


ROBOTICS LAB 10

OpenCV Functions and CV Bridge in ROS



MUNADI SIAL



SCHOOL OF ELECTRICAL ENGINEERING AND COMPUTER SCIENCE
NATIONAL UNIVERSITY OF SCIENCES AND TECHNOLOGY

Overview

This lab will be centered on the following:

- Gaussian Blur
- Canny Edge Detection
- Bitwise Operations
- Color Spaces
- InRange Function
- Centroids
- Perspective Transform
- CVBridge

Review

To load an image:

```
img = cv2.imread("file.jpg", 1)
```

To display an image:

```
cv2.imshow('image1', img)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

To save an image:

```
cv2.imwrite('myImageRotated.jpg', imgA)
```

To get image width and height:

```
rows = img.shape[0]
cols = img.shape[1]
```

Review

To get the BGR values of a specific pixel at location (px, py), we use:

```
img = cv2.imread('bird.jpg', 1)
```

```
val = img[py, px, :]
```

To change pixel colors:

```
img[24,120,:] = (255,0,0)
```

```
img[320,84,:] = (255,255,255)
```


```
img[71,120,:] = (0,0,255)
```

```
img[56,153,:] = (0,0,0)
```

```
img[200,:,:] = (0,255,0)
```

```
img[:,300,:] = (255,0,255)
```

```
img[5:80,300,:] = (88,34,14)
```



Gaussian Blur

To blur an image:


```
blur = cv2.GaussianBlur(img, (5, 5), 0)
```

- The first argument is the image
- The second argument is the kernel size. A larger kernel has more blurring. Kernel sizes can be 3x3, 5x5, 7x7 and so on. The size dimension must be a positive odd number
- The third argument is the standard deviation of the Gaussian function. If it is set to 0, the standard deviation is calculated from the kernel size.



Gaussian Blur

Blurring is a preprocessing step to remove noise in the image data



Edge detection



Edge detection after blurring

Edge Detection

To use the Canny edge detector:

```
edged = cv2.Canny(img, 10, 200)
```

- The first argument is the image
- The second and third arguments are the lower and upper thresholds respectively. The thresholds are for the edge gradients. A gradient above the upper is definitely an edge. A gradient below the lower threshold is definitely not an edge. Gradient values between the thresholds are either edges or non-edges depending on their connectivity of nearby edges



Low gradient






High gradient


:

Bitwise Operations


The following bitwise operations can be used




OR



AND



XOR



NOT

Bitwise Operations

The following bitwise operations can be used

```
img3 = cv2.bitwise_and(img1, img2)
img4 = cv2.bitwise_or(img1, img2)
img5 = cv2.bitwise_xor(img1, img2)
img6 = cv2.bitwise_not(img1)
```

In the first three functions, both images must be the same size.
The bitwise operations are done between corresponding pixels.


Each pixel can be considered to be 0 or 1.
The 0 pixel has an intensity of 0.
The 1 pixel has an intensity greater than 0.

Color Spaces

To change the color space of image from BGR to HSV:

```
img_hsv = cv2.cvtColor(img, cv2.COLOR_BGR2HSV)
```

img_hsv will now have (H,S,V) values instead of (B,G,R)



InRange Function

We can use the **inRange** function to get pixels that have certain values.


```
img2 = cv2.inRange(hsv, np.array([hmin, smin, vmin]),  
np.array([hmax, smax, vmax]))
```

Values of H, S, V range as follows:

Hue: 0-179

Saturation: 0-255

Value : 0-255




:

InRange Function

It is generally preferable to use HSV color space instead of BGR in order to get pixels that have a certain color

```
hsv = cv2.cvtColor(img, cv2.COLOR_BGR2HSV)
img2 = cv2.inRange(hsv, np.array([90, 0, 0]),
np.array([150, 255, 230]))
```


:





Centroids

To get the centroid point (cx, cy), we need a binary image


```
M = cv2.moments(img)
if M['m00'] > 0:
    cx = int(M['m10']/M['m00'])
    cy = int(M['m01']/M['m00'])
```



Original Image



Binary Image




Centroid in Image

Centroids



Original Image



Binary Image



Centroid in Image

Perspective Transformation

To do perspective transformation:

```
pts1 = np.float32([[x1,y1],[x2,y2],[x3,y3],[x4,y4]])  
pts2 = np.float32([[x5,y5],[x6,y6],[x7,y7],[x8,y8]])  
M = cv2.getPerspectiveTransform(pts1,pts2)  
imgP = cv2.warpPerspective(img,M, (cols,rows))
```




CV Bridge

The camera on the robot acquires the images

The images are sent to a
'camera_color_frame/image_raw' topic

A node can subscribe to the above topic to
get the image data

The image data must be converted using the
CV Bridge to an OpenCV object in order to
use OpenCV functions in the node



CV Bridge

A simple CV Bridge use in a node is shown to display the images

```
class ImageSubscriber(Node) :
    def __init__(self):
        super().__init__('image_subscriber')
        self.subscription = self.create_subscription(Image, 'camera_color_frame/image_raw',
                                                    self.listener_callback, 10)

        self.subscription
        self.publisher_ = self.create_publisher(Twist, 'cmd_vel', 10)
        self.move = Twist()
        self.br = CvBridge() # Used to convert between ROS and OpenCV images

    def listener_callback(self, data):
        self.get_logger().info('Receiving video frame')
        img = self.br.imgmsg_to_cv2(data, 'bgr8') # Convert ROS image to OpenCV image
        img = cv2.resize(img, None, 1, 0.5, 0.5, cv2.INTER_CUBIC)
        cv2.imshow('Center', img)
        cv2.waitKey(2)
```

Once, the images are obtained, the OpenCV functions can be used

Lab Tasks

- Download the manual from LMS
- Perform the Lab Tasks as given in the manual and submit it on LMS
- Remember to execute scripts with the terminal