

MAGNETOSTATICS – BIOT- SAVART'S LAW

Introduction

- We have studied that an electrostatic field is produced by static or stationary charges
- If the **charges are moving** with constant velocity, a static magnetic (or magnetostatic) field is produced
- A magnetostatic field is produced by a constant current flow (or direct current)
- This current flow may be due to **magnetization currents** as in permanent magnets, electron-beam currents as in vacuum tubes, or conduction currents as in current-carrying wires
- Applications: motors, transformers, microphones, compasses

Introduction

➤ There are two major laws governing magneto static fields:

➤ (1) Biot-Savart's law

(2) Ampere's circuit law

➤ Like Coulomb's law, Biot-Savart's law is the general law of magneto statics

➤ Like Gauss's law is a special case of Coulomb's law, Ampere's law is a special case of Biot-Savart's law

➤ Ampere's law is applied in problems involving **symmetrical current distribution**


Biot Savart Law

➤ The contribution to the magnetic field (dH) at a point P is directly proportional to:

1. The current I flowing through the wire,
2. The differential length dl ,
3. The sine of the angle between the differential length and the direction to the observation point α

➤ Inversely proportional to:

1. The square of the distance between the current element and the observation point R



Biot Savart Law - Mathematical Form

$$dH \propto \frac{I dl \sin \alpha}{R^2} \quad \text{or} \quad dH = \frac{kI dl \sin \alpha}{R^2}$$

➤ where k is the constant of proportionality

➤ In SI units, $k = 1/4\pi$, so:

$$dH = \frac{I dl \sin \alpha}{4\pi R^2}$$


➤ From the definition of cross product:

$$d\mathbf{H} = \frac{I d\mathbf{l} \times \mathbf{a}_R}{4\pi R^2} = \frac{I d\mathbf{l} \times \mathbf{R}}{4\pi R^3}$$

➤ where $R = |\mathbf{R}|$ and $\mathbf{a}_R = \mathbf{R}/R$

Direction of dH

- The direction of dH can be determined by the right-hand rule with the right-hand thumb pointing in the direction of the current, the right-hand fingers encircling the wire in the direction of dH



Distributed Current Sources

➤ Just as we can have different charge configurations, we can have different current distributions:

1. Line current,
2. Surface current, and
3. Volume current

➤ The source elements are related as:

$$I d\mathbf{l} \equiv \mathbf{K} dS \equiv \mathbf{J} dv$$

➤ **K** is the surface current density (amperes/meter)

➤ **J** is the volume current density (amperes/meter square)

Distributed Current Sources

➤ So in terms of the distributed current sources, the Biot-Savart law becomes:


$$\mathbf{H} = \int_L \frac{I d\mathbf{l} \times \mathbf{a}_R}{4\pi R^2} \quad (\text{line current})$$

$$\mathbf{H} = \int_S \frac{\mathbf{K} dS \times \mathbf{a}_R}{4\pi R^2} \quad (\text{surface current})$$

$$\mathbf{H} = \int_v \frac{\mathbf{J} dv \times \mathbf{a}_R}{4\pi R^2} \quad (\text{volume current})$$

Current Carrying Filament

- Let us apply Biot-Savart law to determine the field due to a straight current carrying filamentary conductor of finite length AB
- We assume that the conductor is along the z-axis with its upper and lower ends respectively subtending angles α_2 and α_1 at P , the point at which \mathbf{H} is to be determined
- Particular note should be taken of this assumption as the formula to be derived will have to be applied accordingly



Current Carrying Filament

- We consider the contribution $d\mathbf{H}$ at P due to an element $d\mathbf{l}$ at $(0, 0, z)$

$$d\mathbf{H} = \frac{I d\mathbf{l} \times \mathbf{R}}{4\pi R^3}$$

- Since $d\mathbf{l} = dz\mathbf{a}_z$ and $\mathbf{R} = \rho\mathbf{a}_\rho - z\mathbf{a}_z$, so:

$$d\mathbf{l} \times \mathbf{R} = \rho dz \mathbf{a}_\phi$$

- Hence:

$$\mathbf{H} = \int \frac{I\rho dz}{4\pi[\rho^2 + z^2]^{3/2}} \mathbf{a}_\phi$$

Current Carrying Filament

➤ Let $z = \rho \cot \alpha, dz = -\rho \operatorname{cosec}^2 \alpha d\alpha$

➤ We get:

$$\begin{aligned}\mathbf{H} &= -\frac{1}{4\pi} \int_{\alpha_1}^{\alpha_2} \frac{\rho^2 \operatorname{cosec}^2 \alpha d\alpha}{\rho^3 \operatorname{cosec}^3 \alpha} \mathbf{a}_\phi \\ &= -\frac{I}{4\pi\rho} \mathbf{a}_\phi \int_{\alpha_1}^{\alpha_2} \sin \alpha d\alpha\end{aligned}$$

➤ Or:

$$\mathbf{H} = \frac{I}{4\pi\rho} (\cos \alpha_2 - \cos \alpha_1) \mathbf{a}_\phi$$

Current Carrying Filament

- This expression is generally applicable for any straight filamentary conductor of finite length
- Notice that \mathbf{H} is always along the **unit vector \mathbf{a}_ϕ** (i.e., along **concentric circular paths**) irrespective of the length of the wire or the point of interest P
- As a special case, when the conductor is **semi-infinite** (with respect to P) so that point A is now at $O(0, 0, 0)$ while B is at $(0, 0, \infty)$; $\alpha_1 = 90^\circ$, $\alpha_2 = 0^\circ$, the above becomes:

$$\mathbf{H} = \frac{I}{4\pi\rho} \mathbf{a}_\phi$$

Current Carrying Filament

- Another special case is when the conductor is **infinite in length**
- For this case, point A is at $(0, 0, -\infty)$ while B is at $(0, 0, \infty)$; $\alpha_1 = 180^\circ$, $\alpha_2 = 0^\circ$, so the equation reduces to:

$$\mathbf{H} = \frac{I}{2\pi\rho} \mathbf{a}_\phi$$

- A simple method to determine the unit vector \mathbf{a}_ϕ is to use the relation below:

$$\mathbf{a}_\phi = \mathbf{a}_\ell \times \mathbf{a}_\rho$$

- \mathbf{a}_ℓ is a unit vector along the line current and \mathbf{a}_ρ is a unit vector along the perpendicular from the line current to the field point

Problem-1

- The conducting triangular loop in the figure carries a current of 10 A. Find H at $(0, 0, 5)$ due to side 1 of the loop

