# **Sensors Training Systems** 6085-00



LabVolt Series

Datasheet

#### **Table of Contents**

General Description	2
List of Available Training Systems	2
Available Training Systems	2
Equipment Description	4

#### **General Description**

The Sensors Training Systems from LabVolt were replaced by the following Festo Didactic equipment set:

• Equipment set TP 1311: Sensors for object detection

Click on the link for more information about the system (topic coverage, list of components, etc.)

Please note that the legacy systems listed below are shown for information purposes only, as the new equipment sets replace them:

#### List of Available Training Systems

Qty	Description	Model number
1	Sensors Training System (Stand-Alone)	588648 (6085-A0)

#### **Available Training Systems**

Sensors Training System (Stand-Alone) 588648 (6085-A0)



The Sensors Training System (Stand-Alone) is designed to familiarize students with the operation of various types of sensors. The training system is stand-alone in that it contains everything required to perform the exercises in the provided courseware, including a power supply, pilot lamps, connection leads, and a work surface for equipment installation.

The system contains a selection of photoelectric, inductive and capacitive

sensors representative of what can be found in the industry. Each sensor is mounted on a flexible support attached to a metal base. The training system provides a comprehensive, high-quality, and cost-effective solution to rapidly build student knowledge in sensors.

The sensor inputs and outputs are accessible through banana jacks, allowing for easy system setup. The sensors are protected against bad connections and reverse polarity, and are identified with the proper symbol on their base. All components meet industrial safety standards.

A block, on which reflectors have been added, is used to observe the characteristics of each sensor.

The Sensors courseware consists of a student manual and an instructor guide. The student manual is divided into seven hands-on exercises. Each exercise provides a clearly stated objective, a discussion, a summary of the exercise procedure, a detailed exercise procedure, and a conclusion. The instructor guide contains the measurement results as well as the answers for each hands-on exercise of the student manual.

#### List of Equipment

Qty	Description	Model number
1	Expanding Work Surface (Small)	582356 (6302-10)
1	DC Power Supply	587962 (6360-A0)
1	Background Suppression Photoelectric Switch	587979 (6373-00)
1	Polarized Retroreflective Photoelectric Switch	587980 (6374-00)
1	Inductive Proximity Switch	587981 (6375-00)
1	Capacitive Proximity Switch	587982 (6376-00)
1	Diffuse Reflective Photoelectric Switch	587983 (6377-00)
1	Fiber-Optic Photoelectric Switch	587985 (6378-00)
1	Reflective Block	582366 (6396-00)
1	Connection Leads	588202 (6491-B0)

#### List of Manuals

Description	manual number
Sensors (Student Manual)	584267 (32606-00)
Sensors (Instructor Guide)	584271 (32606-10)

#### Table of Contents of the Manual(s)

#### Sensors (Student Manual) (584267 (32606-00))

- 1 Introduction to Sensors
- 2 Diffuse Reflective Photoelectric Switches
- 3 Background Suppression Photoelectric Switches
- 4 Fiber-Optic Photoelectric Switches
- 5 Polarized Retroflective Photoelectric Switches
- 6 Capacitive Proximity Switches
- 7 Inductive Proximity Switches

#### **System Specifications**

Parameter	Value
Physical Characteristics	
Intended Location	On a table able to support the weight of the work surface and installed equipment
Dimensions (H x W x D)	555 x 425 x 220 mm (21.9 x 16.7 x 8.7 in)
Net Weight	TBE

#### **Equipment Description**

## Expanding Work Surface (Small) 582356 (6302-10)



The Expanding Work Surface (Small) consists in a perforated plate that can be mounted on the main Work Surface, Model 6301, to increase the work area. The Expanding Work Surface (Small) is one-third the main Work Surface in area.

#### **Specifications**

Parameter	Value
Physical Characteristics	
Dimensions (H x W x D)	30 x 290 x 590 mm (1 x 11.5 x 23 in)
Net Weight	3.2 kg (7.5 lb)

## DC Power Supply 587962 (6360-A0)



The DC Power Supply converts the ac line voltage into a 24 V dc voltage. The power supply is protected against short circuits by an automatic current/limit circuit.

#### **Specifications**

Parameter	Value
Power Requirements	
Voltage	100-240 V ac
Current	4.4 A
Service Installation	Standard single-phase ac outlet
Output	
Voltage	24 V dc
Current	5.0 A
Physical Characteristics	
Dimensions (H x W x D)	120 x 140 x 225 mm (4.7 x 5.5 x 8.9 in)
Net Weight	TBE

## Background Suppression Photoelectric Switch 587979 (6373-00)



The Background Suppression
Photoelectric Switch consists of a light
source and a receiver combined in the
same casing. The sensor is mounted
on a flexible support for easy
positioning. The model has one
normally open and one normally
closed contact, and the electrical
connections are made using miniature
banana jacks.

#### **Specifications**

Parameter	Value
Light Source	Infrared LED, 880 nm
Maximum Range	10 cm (4 in)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

## Polarized Retroreflective Photoelectric Switch 587980 (6374-00)



The Polarized Retroreflective
Photoelectric Switch consists of a light
source and a receiver combined in the
same casing. The sensor requires a
special retroreflective surface. The
sensor is mounted on a flexible
support for easy positioning. The
model has one normally open and one
normally closed contact, and the
electrical connections are made using
miniature banana jacks.

#### **Specifications**

Parameter	Value
Light Source	Visible red LED, 660 nm
Maximum Range	3 m (10 ft)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

### Inductive Proximity Switch 587981 (6375-00)



The Inductive Proximity Switch is sensitive to metals. The sensor is mounted on a flexible support for easy positioning. The model has one normally open and one normally closed contact, and the electrical connections are made using miniature banana jacks.

#### **Specifications**

Parameter	Value
Maximum Range	10 mm (0.4 in)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT

Parameter	Value
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

## Capacitive Proximity Switch 587982 (6376-00)



The Capacitive Proximity Switch is sensitive to every material. The sensor is mounted on a flexible support for easy positioning. The model has one normally open and one normally closed contact, and the electrical connections are made using miniature banana jacks.

#### **Specifications**

Parameter	Value
Maximum Range	25 mm (1 in)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

## Diffuse Reflective Photoelectric Switch 587983 (6377-00)



The Diffuse Reflective Photoelectric Switch consists of a light source and a receiver combined in the same casing. The sensor is mounted on a flexible support for easy positioning. The model has one normally open and one normally closed contact, and the electrical connections are made using miniature banana jacks.

#### **Specifications**

Parameter	Value
Light Source	Visible red LED, 700 nm
Maximum Range	20 cm (8 in)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

### Fiber-Optic Photoelectric Switch 587985 (6378-00)



The Fiber-Optic Photoelectric Switch consists of a fiber-optic photoeletric switch whose light source is a visible red LED. The sensor is mounted on a flexible support for easy positioning. The model has one normally open and one normally closed contact, and the electrical connections are made using miniature banana jacks.

#### **Specifications**

Parameter	Value
Light Source	Visible red LED, 680 nm
Maximum Range	10 cm (4 in)
Supply Voltage	24 V dc
Contacts	
Туре	SPDT
Ratings	24 V dc - 3 A
Physical Characteristics	
Dimensions (H x W x D)	400 x 70 x 170 mm (16 x 3 x 7 in)
Net Weight	500 g (1.1 lb)

## **Reflective Block** 582366 (6396-00)



The Reflective Block consists of a block with various types of reflection surfaces: white, black, shiny metallic, matte black metallic, and retroreflective. The dimensions of the block are: 75 x 75 x 75 mm (3 x 3 x 3 in).

#### **Specifications**

Parameter	Value
Surfaces	White, black, shiny metallic, matte black metallic, retroreflective
Physical Characteristics	
Dimensions (H x W x D)	75 x 75 x 75 mm (3 x 3 x 3 in)
Net Weight	300 g (0.7 lb)

## Connection Leads 588202 (6491-B0)

with stacking 2 mm banana plugs.

The Connection Leads consist in extraflexible electrical leads terminated

#### **Specifications**

Parameter	Value
Electrical Leads	
Quantity	7
Length	45 cm (18 in)
Connectors	2 mm banana plugs
Rating	10 A
Physical Characteristics	
Net Weight	100 g (0.2 lb)

Reflecting the commitment of Festo Didactic to high quality standards in product, design, development, production, installation, and service, our manufacturing and distribution facility has received the ISO 9001 certification.

Festo Didactic reserves the right to make product improvements at any time and without notice and is not responsible for typographical errors. Festo Didactic recognizes all product names used herein as trademarks or registered trademarks of their respective holders. © Festo Didactic Inc. 2019. All rights reserved.

#### Festo Didactic SE

Rechbergstrasse 3 73770 Denkendorf Germany

P. +49(0)711/3467-0 F. +49(0)711/347-54-88500

#### Festo Didactic Inc.

607 Industrial Way West Eatontown, NJ 07724 United States

P. +1-732-938-2000 F. +1-732-774-8573

#### Festo Didactic Ltée/Ltd

675 rue du Carbone Québec QC G2N 2K7 Canada

P. +1-418-849-1000 F. +1-418-849-1666

www.labvolt.com

www.festo-didactic.com